



72040

Adjustable Strut Mount

Q1: I am installing a 72040 adjustable strut mount on my Ford Mustang. The mount seems to be all one piece and won't come apart. What should I do?

A1: The plastic strut bearing is pressed onto the metal strut mount. Use a pry bar or wide blade screw driver to pry the plastic bearing off of the metal plate. It will take a moderate amount of force but they will separate.

